

Power

Control CV Gate

Frequency Modulation Pulse Width PWM

Pulse Saw Tri. CV In PWM In

Range Waveform

Frequency Delay

LFO Tri. Rect. Trigger

Mixer VCO Noise External

In Out

Noise White Pink White Pink

ADSR Attack Decay Sustain Release

Out Inv. Out Gate In

VCF Cutoff Freq. Resonance Mod. Amount Env. Amount

Kbd In Out CV In

VCA Output Level Initial Level Mod. Amount

Gate EG In Out CV In